

MONOLIT Firmware Update Guide

1. **Connect MONOLIT to your computer**
Use a USB cable to connect MONOLIT to your laptop or computer.
2. **Open the update menu**
On the MONOLIT device, go to **Settings** and select **Firmware Update**.
Note: You can also access the update menu by holding the left black button below the screen while plugging in the USB cable.
3. **MONOLIT will appear as an external drive**
After selecting the firmware update option, MONOLIT will appear on your computer as an external drive.
4. **Update the firmware file**
 - In the root folder of the drive, locate the firmware file.
 - Replace it with the new version. If the device doesn't allow you to overwrite the file immediately, manually delete the old file and upload the new one.
5. **Complete the update**
The device will automatically reboot after the firmware file is replaced.

MONOLIT ファームウェア更新ガイド

1. **MONOLITをパソコンに接続する**
USBケーブルを使って、MONOLITをノートパソコンまたはパソコンに接続します。
2. **アップデートメニューを開く**
MONOLITデバイスで、**Settings(設定)**に移動し、**Firmware Update(ファームウェア更新)**を選択します。
注: USBケーブルを差し込む際に、画面下の左側の黒いボタンを押し続けると、アップデートメニューに入ることもできます。
3. **MONOLITが外部ドライブとして表示される**
ファームウェア更新オプションを選択すると、MONOLITはパソコンに外部ドライブとして表示されます。
4. **ファームウェアファイルを更新する**
 - ドライブのルートフォルダにファームウェアファイルがあります。
 - 新しいバージョンに置き換えてください。すぐに上書きできない場合は、古いファイルを手動で削除してから、新しいファイルをアップロードしてください。
5. **アップデートを完了する**
ファームウェアファイルが置き換えられた後、デバイスは自動的に再起動します。

